

Artikelnummer: 323998



AdLuminis Funk-Fernbedienung mit Handsender

Diese Bedienungsanleitung enthält wichtige Informationen!

Technische Daten:

Modell-Nr.:	T-RC101
Eingangsspannung:	10-30V DC
Laststrom max.:	25A
Frequenz:	433MHZ
Max. Empfangsbereich:	50m
Wasserdicht:	ja
Kompatibel mit:	Allen Leuchten mit max. Strom unter 25A
Installation:	Ein Kabel zum Anschluss der Batterie, ein weiteres zum direkten Anschluss der Leuchte

Wie programmiert man die Fernbedienung und den Empfänger?:

1. Drücken Sie die Reset-Taste und lassen Sie sie los, die Leuchte blinkt automatisch zweimal.
2. Drücken Sie eine beliebige Taste A, B, C, D innerhalb von 5 Sekunden, die Leuchte blinkt dreimal und zeigt damit an, dass die Programmierung abgeschlossen ist.
3. Um die Programmierung aus dem Speicher zu löschen, drücken Sie die Reset-Taste und lassen Sie sie los, bis die Lampe 5 Mal blinkt.

Hinweis: Alle Fernbedienungen und Empfänger sind original programmiert. Der obige Vorgang ist also nicht erforderlich, es sei denn, Sie müssen eine Fernbedienung oder einen Empfänger austauschen.

Funktionen:

- Ein/Aus - Modell
- neun Blitzmodi
- SOS-Notfallmodus

Anleitung:

- Taste A: Einschalten / Ausschalten
Taste B: Vorwärts blinken (Taste A muss auf „ON“ stehen)
Taste C: Rückwärts blinken (Taste A muss auf „ON“ stehen)
Taste D: SOS-Exklusiv-Modus (Ein weiterer Druck schaltet SOS aus. Wenn D eingeschaltet ist, sind andere Tasten nicht verfügbar)

Details zu den Blinkmodi:

- Modus 0: Immer an (kein Blinken)
Modus 1: (40ms Ein + 40ms Aus)*3 + 240ms Aus
Modus 2: (40ms Ein + 40ms Aus)*41 + (300ms Ein + 300ms Aus)*10
Modus 3: 250ms Ein + 250ms Aus
Modus 4: 150ms Ein + 150ms Aus + 150ms Ein + 650ms Aus
Modus 5: 330ms Ein + 330ms Aus
Modus 6: (40ms Ein + 40ms Aus) + (42ms Ein + 42ms Aus) +(44ms Ein + 44ms Aus) + + (398ms Ein + 400ms Aus)
Modus 7: 500ms Ein + 500ms Aus
Modus 8: (400ms Ein + 398ms Aus) + (396ms Ein + 394ms Aus) + + (42ms Ein + 40ms Aus)
Modus 9: (40ms Ein + 40ms Aus)*1 + 460ms Aus + (40ms Ein + 40ms Aus)*2 + 460ms Aus + (40ms Ein + 40ms Aus)*3 + 460ms Aus + .. + (40ms Ein + 40ms Aus)*10 + 460ms Aus
Modus 10: SOS-Modus (200ms Ein + 200ms Aus)*3 + 300ms Aus + (400ms Ein + 200ms Aus)*3 + 300ms Aus + (200ms Ein + 200ms Aus) *3 + 1100ms Aus

Importeur:



FK Söhnchen GmbH & Co. KG
Im Dahl 1 - 58579 Schalksmühle

Hersteller:



ABC Onlinevertrieb GmbH
Loh 2 - 58339 Breckerfeld

Item No.: 323998



AdLuminis Wireless Remote Controller for all lights

Parameters:

Model No:	T-RC101
Input Voltage:	10-30V DC
Max Amp:	25A
Frequency:	433MHZ
Effective distance:	50m
Waterproof:	yea
Compatible with:	All lights with max current under 25A
Installation:	one cable to connect the battery, another one to connect the light directly

How to program the remote and receiver?:

1. Press the Reset key and release, the light will flash twice automatically.
2. Press any key A, B, C, D within 5 seconds, the light will flash 3 times indicating that the programming is completed.
3. To erase the programming from memory --- Press the Reset key and release it until the light flash 5 times.

Note: All remote and receiver is programmed originally. So the above operation is no need unless you need to change a remote or a receiver.

Functions:

- On/Off - Model
- 9 flash patterns
- SOS emergency mode

Intructions:

- Key A: Turn on/off
Key B: Flash forward (Key A needs to be "ON")
Key C: Flash backward (Key A needs to be "ON")
Key D: SOS Exclusive mode. (One more press to turn off SOS, when D is on, other keys are not available)

Details of Flash Patterns:

- Pattern 0: Always On (No Flashing)
Pattern 1: (On 40ms + Off 40ms)*3 + Off 240ms
Pattern 2: (On 40ms + Off 40ms)*41 + (On 300ms + Off 300ms)*10
Pattern 3: On 250ms + Off 250ms
Pattern 4: On 150ms + Off 150ms + On 150ms + Off 650ms
Pattern 5: On 330ms + Off 330ms
Pattern 6: (On 40ms + Off 40ms) + (On 42ms + Off 42ms) + (On 44ms + Off 44ms) + + (On 398ms + Off 400ms)
Pattern 7: On 500ms + Off 500ms
Pattern 8: (On 400ms + Off 398ms) + (On 396ms + Off 394ms) + + (On 42ms + Off 40ms)
Pattern 9: (On 40ms + Off 40ms)*1 + Off 460ms + (On 40ms + Off 40ms)*2 + Off 460ms + (On 40ms + Off 40ms)*3 + Off 460ms + + (On 40ms + Off 40ms)*10 + Off 460ms
Pattern 10: SOS Pattern (On 200ms + Off 200ms)*3 + Off 300ms + (On 400ms + Off 200ms)*3 + Off 300ms + (On 200ms + Off 200ms) *3 + Off 1100ms

Importer:



FK Söhnchen GmbH & Co. KG
Im Dahl 1 - 58579 Schalksmühle

Manufacturer:



ABC Onlinevertrieb GmbH
Loh 2 - 58339 Breckerfeld